



ASSEMBLY INSTRUCTIONS

01831 Calypso Cabana

Thank you for purchasing this Texsport cabana. Please read and understand each step of the set-up instructions. We encourage you to set-up this cabana at least once prior to your camping trip, ensuring that you have a satisfactory understanding of the set-up process. We hope you enjoy your new cabana and that it will give you many years of camping pleasure.

Do not apply excessive force to this product.

PARTS LIST:

- A 1 Cabana skin
- B 1 Long pole
- C 2 Sets of short poles
- D Stakes

NOTE:

Prepare your camp site by removing all sharp stones, twigs, etc. The site should be flat and have no depressions that could collect rain water.



Step 1 - Spread the cabana skin.



Step 2 - Assemble 1 short pole and push it through the roof sleeve, ferrule side first. Repeat this step for the remaining short pole. DO NOT insert the pin into the pole.



Step 3 - Assemble the long pole and push it up through the sleeve from one side, over the two roof poles, down to side of the cabana skin.



Step 4 - Insert the pin and ring into the ferrule end of the long side pole. Do this on both ends.




Step 5 - Insert the pin and ring into the ferrule of the short rear roof poles.



Step 6 - Insert the pole's pin into the grommeted web strap above the front opening of the cabana.



Step 7 - Secure all poles with ties on the roof skin as shown above.



Step 8 - Stake down at all pole rings.



Step 9 - Add weight (sand) in the bags to secure your cabana in high winds.

WARNING:

Texsport cabana fabrics are flame retardant treated per C.P.A.I.-84 specification. However, for your safety, we recommend that NO OPEN FLAME BE USED IN OR NEAR YOUR CABANA.

SOME ADDITIONAL INFORMATION:

Always secure your cabana (with the cabana stakes included). Stake one corner, then stake each consecutive corner in a clockwise rotation. Make sure the cabana remains tight. Always place your cabana a safe distance from your campfire - unstaked cabana placed upwind of the fire can be blown into the fire. Cabana placed downwind of the fire are often showered with tiny sparks that can burn holes into the lightweight fabrics of your cabana.

WATERPROOFING YOUR CABANA:

Texsport cabanas are made from coated water-repellent fabrics. However, the sewing process, necessary in all cabana fabrication, can cause water leakage where the sewing needles have perforated the fabric in the seams. Without treatment the cabana will leak. Every new cabana needs to be seam sealed to make it water tight. We recommend using Texsport Spray Waterproofing/Seam Sealer which may be found at your local outdoor outfitter or camping store. DO NOT APPLY SEAM SEALER TO ZIPPERS.

STAKES:

All cabanas should be staked down. The stakes supplied with your cabana are effective for most conditions; however, specialized stakes are recommended in certain cases:

- a. Sand Stakes:..... Long broad stakes designed to hold in loose sand.
- b. Steel Stakes: Most effective in hard, rocky or frozen soil. These can rust and their sharp edges could damage the cabana if stored with the cabana. In extremely hard soil a steel rod can be used to make the starter hole.
- c. Skewer Stakes:... Lightweight, but less holding power that the standard stakes.

ZIPPERS:

If zippers stick, lubricate with silicone. Never force a zipper which has material caught in it as this will bend the slider and prevent the zipper from closing. Continual use in a sandy environment can cause the slider to erode and fail to close the zipper.

STORAGE:

Cabanas should be stored dry and loosely folded away from heat and water. Keep out of reach of mice as they like to nest in cabanas. Never store directly on concrete as moisture and chemicals in concrete may damage the nylon.

WASHING:

Hand wash with a sponge using a mild soap. Never use detergents or washing machines as they may damage the coating or seams. Remember to use seam sealer once cabana has been washed to insure waterproofing.

HOW LONG WILL A NYLON CABANA LAST?

Various conditions will affect the length of service which you receive:

- a. A nylon cabana which is left erected all summer may last only one or two seasons as the sun's ultra-violet rays damage the nylon.
- b. Never store a cabana wet or damp as mildew may develop. It will not harm nylon, however, mildew is unsightly and may damage other parts of the cabana (i.e. zipper tapes)
- c.. Avoid spraying insect repellent or hair sprays, etc. on cabana fabric as they may be harmful.

REPAIR:

For small tears use a an adhesive backed rip-stop nylon patch. We recommend Texsport Nylon Cabana Repair Kit (#14113) which may be found at your local outdoor outfitter or camping store.

QUESTIONS:

If you should have any questions, problems or comments, please call our Customer Service Department at 1-800-231-1402 or e-mail info@texsport.com. This Department is open M-F from 8 a.m.-5 p.m. CST.