



CONTENTS

- 1. Rear Rest Section (1pc)
- 2. Front Rest Section (1pc)
- 3. Frame Attachment Knobs (2pc)
- 4. Legs (3pcs)
- 5. Wing Nuts (3pcs)
- 6. Buttstock Clamp (1pc)
- 7. Buttstock Strap (1pc)
- 8. Buttstock Clamp Adjustment Knobs (3pc)
- 9. Buttstock Strap (1pc)
- 10. Vertical Adjustment Wheel (1pc)
- 11. Threaded Support Shaft (1pc)
- 12. Threaded Support Shaft Screw (1pc)
- 13. Rest (1pc)
- 14. Rest Screw (1pc)
- 15. Padded Shooter's Rest (1pc)
- 16. Folding Adjustment Knobs (2pc)

ASSEMBLY INSTRUCTIONS:

Remove all protective wrapping from all rest components. Secure the Rear Rest Section(#1) to the Front Rest Section(#2) using the two Frame Attachment Knobs(#3) as shown in the diagram. Screw the Rest Legs(#4) onto the Rear Rest Section(#1) & the Front Rest Section(#2). The two taller Legs should attach to the Front Rest Section(#2) and the smaller Leg should attach to the Rear Rest Section(#1). Securely tighten all Legs using the wing nuts(#5) provided.

Insert the Buttstock Clamp(#6) into the Rear Rest Section(#1) and fix the clamp into position using one of the Buttstock Adjustment Knobs(#8). Slide the Buttstock Strap(#7) onto the Buttstock Clamp(#6) as shown in the diagram.

Thread the Vertical Adjustment Wheel(#10) onto the Threaded Support Shaft(#11) until it is approximately to the middle of the shaft. Insert the Threaded Support Shaft(#11) into the Front Rest Section(#2) and tighten down at the appropriate height with the Threaded Support Shaft Screw(#12). Place the Rest(#13) onto the Threaded Support Shaft(#11) and lock it down with the Rest Screw(#14). Attach the Padded Shooter's Rest(#15) to the Rest(#13) by using the hook & loop attachments.

Use the Folding Adjustment Knobs(#16) to secure the Front Rest Section Arms in place when shooting or sighting in your firearm.

USAGE INSTRUCTIONS:

Step 1: Make sure the rest is level and does not wobble. Adjust the Legs to make the rest level & tighten screws appropriately.

Step 2: Aligning the rest to the target. Place the rest on a bench or flat surface. Looking through the gun's sights or scope, align the gun so it is horizontally centered on the target. Vertical adjustments can be made by twisting the Vertical Adjustment Wheel.

Step 3: Proceed to sight your gun in as you normally would.