



FILTER-REGULATOR SET

1. Installation instruction

1. The assembly of all calibration shall meet the maximum flow requirement.
2. Maximum pressure of 144PSI.
3. Direction-air flow in the triangle "►" on the primary unit.
4. Place-as close to the unit to be protected as possible.
5. Place-free of direct sun shine, hot area, and hazardous chemicals.
6. The water drainage shall be deployed beneath the water discharges for outlet of water into proper area.

2. Regulation:

1. Regulation of pressure
 - a. Raise off the part (11)and turn it clockwise to have the pressure up and counterclockwise to have the pressure down.
 - b. Regulate the pressure to the desired level and press down the part(11)to lock it up.
2. Drainage
 - a. If no pneumatic pressure , water will discharge the air into the atmosphere.
 - b. When the water level exceeds the maximum limit, please close the pressure, and let the unit has no pneumatic pressure for draining off the water to keep optimal dehumidification.

3. Maintenance:

1. Shut off the air supply and discharge the air into the atmosphere.
2. Turn off the part (3) counterclockwise and then turn off the part (4) counterclockwise to remove the part (5) filter.
3. The filter that makes the air flow outward is available for repeated use.
4. Clean the transparent P. C. cup with a clean and dry cloth. Do not use any chemical that would be hazardous to the P. C. material.

LUBRICATOR

1. Installation instruction

1. Site-as close to the unit to be lubricated as possible.
2. Direct installation of filtered - pressure regulator before the lubricator .
3. Add the lubricant into the oil cup.

2. Oil drop regulation

1. Regulation of the needle vaive: Turn it clockwise for loss oil drop.
Turn it counterclockwise for more oil drop.
2. Air flow regulation: After setting the needle valve.
More air flow more oil droo.
Less air flow, less oil drop.

3. Oiling:

1. Oiling is available without closing the air piping.
2. Turn off the part (43) counterclockwise. .
3. Use ISO-VG32 or similar lubricants.
4. After adding oil to the maximum level,tighten the part(43) to have oil drop.
5. Do not remove the oil cup directly for oiling.

4. Maintenance

1. Shut off the air supply and discharge the air into the atmosphere.
2. Turn off the part (3) counterclockwise and remove the part (42).
3. Clean the transparent P. C. cup with a clean and dry cloth .Do not use any chemical that would be hazardous to the P. C. material.
4. When assembling the kit again, please be sure that the SEAL and O-RING are in correct positions.

NOTICE:

1. The product in reference is applicable in industrial pressure systems rather than in premises of pressure and temperature exceeding the marked ones. This is not applicable in other fluids neither such as alcohol, gas, and gasoline. as it is hazardous to the products by presenting leakage or flame.
2. The plastic cups and parts, when exposed to paints, poor oil products and Chemicals (resin, polyethylene, acetic acid and others)would lead to aging in material in material and other defects.