

COZY PRODUCTS

Safe, Energy-Saving Personal Heaters

Formerly "Indus-Tool"

www.cozyproducts.com
sales@cozyproducts.com

Chicago, IL 60612

FOOTWARMER

Thermostatically-controlled
uniform radiant heat

For use on concrete, stone or tile floors. (Do not use on carpeting or wood floors.)



INSTRUCTIONS:

- 1 Plug in
- 2 Push switch on cord to "ON" position (switch is illuminated when "ON")
- 3 Observe safety precautions:
 - Do not cover
 - Do not fold or twist
 - Do not use if cut or damaged
 - Do not use if you have impaired sensation in your extremities
 - Keep from pets and children
 - Keep dry and free from obstruction
 - For "indoor use" only



Certificate No.: CU72131500
UL 499 (13th edition) Revision March 5, 2008
CAN/CSA C22.2.88-58 + G11 (R2008)

REORDER: #FW 14" x 21" 90 watts
#FWB 16" x 36" 135 watts

GENERAL INFORMATION:

HOW IT WORKS

FOOTWARMER has been pre-tested and set to the correct temperature for use. The mat has been designed so warmth travels upward, circulating around your feet and legs.

TEMPERATURE

FOOTWARMER contains an electric heating element that produces a uniform radiant heat. It is thermostatically controlled so that the heat will be maintained at a constant temperature. The heating element is molded within the rubber to eliminate the danger of fire or electrical shock. (As with any new heated rubber product, the rubber odor may be noticeable when plugged in for the first time. This is temporary, and will dissipate quickly.)

PLACEMENT

For use on concrete, stone or tile floors. Do not use on carpeting or wood floors. Take care as to what type of surface you place the mat on – some delicate surfaces may discolor or crack from even this gentle heat. If you are not sure, place some cardboard under the mat for insulation.

IMPORTANT: PLEASE READ BEFORE USE

This appliance has a polarized plug. To reduce risk of electric shock, this plug is intended to fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

WARRANTY: This product is warranted against defects in materials and workmanship for a period of six months from the shipping date. At the option of Cozy Products, we will either replace or repair the defective unit.

WARNING: Take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to suitability or fitness of these devices for any specific application. While product includes an overtemperature regulator, misuse may cause failure, damaging the product, mounting surface or work area. Do not drape or cover product with any material. Always allow heat to escape. Protect from puncture. Turn off when not in use.

Use caution as you would with any hot product, especially if you have any issues with loss of feeling in the areas affected by the heat.

FOOTWARMER

À commande thermostatique
chaleur rayonnante uniforme

Pour utilisation sur des planchers de béton, de pierres ou sur du carrelage.

(Ne pas utiliser sur du tapis ou des planchers en bois).



INSTRUCTIONS :

1 Branchement

2 Poussez l'interrupteur sur le cordon à la position « ON » (l'interrupteur est illuminé lorsqu'à « ON »)

3 Observez les mesures de sécurité :

- Ne pas recouvrir
- Ne pas plier ou tordre
- Ne pas utiliser si coupé ou endommagé
- Ne pas utiliser si vous avez une sensation réduite dans vos extrémités
- Tenir loin des enfants et des animaux domestiques
- Garder sec et exempt d'obstructions
- Pour « usage à l'intérieur » uniquement



No. de certificate : CU72131500
UL 499 (13^{ème} édition) Révision 5
Mars 2008
CAN/CSA C22.2.88-58 + G11

INFORMATION GÉNÉRALE :

LE FONCTIONNEMENT

FOOTWARMER a été pré testé et réglé à la bonne température pour être utilisé. Le tapis a été conçu de sorte que la chaleur se déplace vers le haut, et circule autour de vos pieds et de vos jambes.

TEMPÉRATURE

FOOTWARMER contient un élément électrique chauffant qui produit une chaleur rayonnante uniforme. Il est commandé par thermostat de sorte que la chaleur sera maintenue à une température constante. L'élément chauffant est moulé dans le caoutchouc pour éliminer le danger d'incendie et de choc électrique. (Comme avec tout nouveau produit chauffant en caoutchouc, une odeur de caoutchouc peut se faire sentir lorsque branché pour la première fois. Cela est temporaire et se dissipera rapidement).

PLACEMENT

Pour utilisation sur des planchers de béton, de pierres ou sur du carrelage. Ne pas utiliser sur du tapis ou des planchers en bois. Faire attention au type de surface où le tapis est placé – certaines surfaces délicates peuvent se décolorer ou craquer même si cette chaleur est douce. En cas de doute, placer un carton sous le tapis pour agir comme isolant.

IMPORTANT : VEUILLEZ LIRE AVANT D'UTILISER

Cet appareil a une fiche polarisée. Afin de réduire le risque de choc électrique, cette fiche ne s'insère dans une prise polarisée que d'une seule façon. Si la fiche ne s'insère pas complètement dans la prise, inversez la fiche. Si la fiche ne s'adapte toujours pas à la prise, faites appel à un électricien qualifié. Ne modifiez pas la fiche d'aucune façon.

GARANTIE : Ce produit est garanti contre toutes défauts dans le matériel et la main d'oeuvre pour une période de six mois à partir de la date d'expédition. À la discrétion de Cozy Products, nous remplacerons ou réparerons l'unité défectueuse.

AVERTISSEMENT : Avant d'utiliser cet appareil, prenez le temps de déterminer s'il est approprié, adéquat et sécuritaire pour l'usage prévu. Puisque les applications peuvent varier considérablement les unes des autres, le fabricant ne fait aucune déclaration ni n'accorde aucune garantie quant à l'adéquation de ces appareils à une application donnée. Bien que ce produit inclut un régulateur de surchauffe, une mauvaise utilisation peut causer une panne, peut endommager le produit, la surface de montage ou la zone de travail. N'enveloppez ni ne couvrez le produit avec aucun matériel. Laissez toujours l'air s'échapper. Protégez contre les perforations. Éteignez lorsque non utilisé.

Soyez prudent comme avec tout produit chauffant, spécialement si vous avez des problèmes avec une perte de sensation dans les endroits affectés par la chaleur.

NOUVELLE COMMANDE :
#FW 14" x 21" 90 watts
#FWB 16" x 36" 135 watts