



**INSTALLATION INSTRUCTIONS:**

1. Push window slider of top bracket into top window molding, hold in place.
2. Push window slider of bottom bracket into bottom window molding.
3. While maintaining firm tension of two brackets into molding, insert two screws to hold brackets together and tighten them securely.
4. Test rack to ensure it is tightly attached to vehicle before placing heavy objects on it.

**WARNING NEVER PUT A LOADED GUN ON THE RACK.**