

**READ THIS FIRST:**

Read and follow all instructions carefully before beginning installation.

**LISEZ CECI EN PREMIER:**

Lire et suivre toutes les instructions attentivement avant le montage.

**LEA ESTO PRIMERO:**

Lea y siga todas las instrucciones cuidadosamente antes de iniciar la instalación.

# Installation Instructions Instrucciones de instalación Directives de montage For P/N 85069XX

Plugin Harness for the Tekonsha & Reese  
Towpower brand Brake Controllers


**TOOLS REQUIRED:**

Wire stripper & Cutter, pliers



## Brake Control Plugin Wiring Instructions

1. Disconnect battery terminals.
2. Connect wires according to the chart.
3. Secure wiring harness under dash.
4. Plug Brake Control Harness into the Brake Controller
5. Reconnect battery terminals.
6. Test Brake Control with installed harness for correct operation.

\* **Vehicle Wiring Chart** (Note: connect wires by function ONLY)

Refer to vehicle manual for related fuse locations (typically installed at the factory).

Function	Connect	Brake Control Wiring Adapter
Battery Positive	To	Black
Stoplight Signal	To	Red
Ground	To	White
Output To Trailer	To	Blue

## **⚠ WARNING**

- All connections must be complete to function properly. Test and verify installation with a test light, circuit tester or trailer once installed.
- Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:
- Max. Right Turn, Left Turn, Stop, & Tail Light Circuits: (7.5 amps)
- Max. (+) Battery, Reverse, and Electric Brake Circuits: (30 amps)
- Read vehicle's owner's manual & instruction sheet for additional information. Additional fusing may be required

Cequent Consumer products  
29000-2 Aurora Road  
Solon, OH 44139  
www.ReeseBrands.com

85069IN Rev.A 10/15