

Today, we're going to show you how to install the Endurance 40920 7-blade connector. Make sure that your vehicle is listed in the application guide at www.hopkinstowingsolutions.com.

(Note: This part will work only on vehicles that have a factory 7-blade connector.)

Approximate install time is 15 minutes.

The first step is to remove the plug from the back of the factory 7-blade connector. Press to release the locking tab.

Next, mount the Hopkins replacement connector to the existing vehicle mounting location. The Hopkins connector will match most OEM twist-mount brackets.

Use the included packets to apply a small amount of dielectric grease to all electrical connections. This helps prevent corrosion.

Connect the vehicle plug to the back of the new connector. Secure the connector with locking tabs.

Last, return the safety tab to its original socket.

Installation is complete for the Endurance 40920 7 - Blade Connector.

We recommend you verify all electrical functions are working properly while the vehicle is running. If you think you need more information, call 1-800-835-0129 to speak with a customer representative.