

Door Flap Installation Instructions

Unscrew 3 star shaped bolts.
Line up clear vinyl Door Flap with
the 3 holes in the door frame.

Attach vinyl Door Flap to door frame
using the 3 star shaped bolts.

