

REAR HITCH KIT (15696)

This kit is **ONLY** used on 2014 and newer 200 series LUTVs

As illustrated below, this kit consists of:

- | | |
|---------------------|--------|
| 16043-2 Hitch Mount | Qty: 1 |
| 15422 3/8 Bolt | Qty: 4 |
| 15442 3/8 Nut | Qty: 4 |

TOOLS REQUIRED*

- 9/16" Socket & Ratchet
- 9/16" Wrench



Procedure:

- 1** Position the hitch mount so that the bolt holes line up with the swingarm bolt holes and so that the hitch mount is nearly parallel to the ground.
- 2** Install the 3/8" bolt from the outside such that they pass through the swingarm and hitch mount.
- 3** Install the lock nuts and tighten.

