

ADDING A 100 WATT PANEL TO A GRAPE SOLAR 100x KIT

1. Cover all panels with cloth or cardboard to prevent electrical output.
2. Connect the two 16" MC4-to-MC4 cables in this kit to the output leads of the expansion panel.
3. Disconnect the last panel of the current array from the parallel cable inputs (or branch connector set).
4. Connect the outputs of the two panels to the MC4 branch connector set included in this kit.
5. Connect the outputs of the two MC4 branch connectors to the parallel cables inputs (the ones that the 4th panel was originally connected to) or the last set of branch connectors in the pre-existing array (you will have a free space from where the last panel was disconnected in step #3).
6. Remove covering from panels.

Please contact support@grapesolar.com with any questions