



CCTC ASSEMBLY INSTRUCTIONS

www.kamprite.com



1



REMOVE CCTC COT FROM BAG

2



LAY THE COT ON ITS SIDE & GRASP EACH SIDE

3



CAREFULLY OPEN THE COT

4



STAND BEHIND THE COT
(LEGS FACING AWAY FROM YOU)

5



GRASP LEGS AT TOP; CAREFULLY
PULL OUTWARDS TO OPEN COT

6



STAND COT UPRIGHT & PLACE TENT ON TOP;
ZIP TENT TO COT FRAME ALONG BOTH SIDES

7



POSITION FIBERGLASS POLES;
ATTACH TENT W/SUPPLIED CLIPS

8



SECURE POLE TIP
INTO FIRST EYELET

9



FOLD ENDS UNDER;
ATTACH HOOK & LOOP
SYSTEM TOGETHER

10



ATTACH ONE SPREADER
ROD TO EACH END OF TENT
(1/2 WAY DOWN)

OPTIONAL CONFIGURATIONS



INCLUDED RAINFLY



STAND-ALONE COT



ON-GROUND CAMPING