

EA120T Installation Instructions

FINISHING INSTALLATION:

1. Install the 1.5"X2"X84" long stuffer seal between the wall-sleeve and the unit. A flat-bladed screwdriver or putty knife is recommended.



2. Assemble the trim frame by inserting top and bottom pieces into side pieces and snapping into place



3. Pull cord through trim frame then slide over unit until flush with wall




EA120T Instrucciones de montaje

TERMINAR LA INSTALACIÓN:

1. Instale el sello de relleno de 1.5"X2"X84" entre la junta de pared y la unidad. Se recomienda usar un destornillador de punta plana o una espátula para masilla.



2. Ensamble el marco moldeado insertando las piezas de arriba y de abajo en las piezas laterales y luego hagalas encajar en su sitio.



3. Tire la cuerda a través del marco moldeado, luego deslice sobre la unidad hasta que quede alineada con la pared.

