



## THE POWER LOADER ADAPTER BRACKET FOR UTILITY VEHICLES MODEL: PLUT1

### **⚠ WARNING**

READ ALL INSTRUCTIONS BEFORE USING THE PLUT1

NOTE: Failure to read instructions before use could result in injury or death.

### **Instructions for Installation and Use:**

#### **CONTENTS:**

2 - UTILITY BRACKETS  
2 - 1" SPACER BARS  
2 - 1/4" X 2 3/4" BOLTS  
2 - 1/4" LOCKNUTS  
4 - 5/16" LOCKNUTS  
8 - 5/16" FLAT WASHERS  
2 - 5/16" U-BOLTS



#### **STEP 1:**

ATTACH UTILITY MOUNTING BRACKETS TO THE POWER LOADER USING HARDWARE PROVIDED WITH POWER LOADER.

#### **STEP 2:**

ATTACH POWER LOADER ASSEMBLY TO VEHICLE'S TOP FRONT BUMPER TUBE WITH U-BOLTS, FLAT WASHERS & LOCKNUTS PROVIDED WITH PLUT1 ADAPTER KIT. TIGHTEN SECURELY.

#### **NOTE:**

ON SOME UTV'S THE BOTTOM BAR OF THE BRUSHGUARD IS EVEN OR PARALLEL WITH TOP BAR. IN THIS INSTANCE YOU MAY INSTALL ONE OR BOTH OF THE 1" SPACER BARS BETWEEN ADAPTER BRACKET AND BRUSHGUARD USING 2 - 1/4" X 2 3/4" BOLTS, 4- FLAT WASHERS AND 2 - 1/4" LOCKNUTS. **SEE FIG. 1 AND 2.** THIS WILL KEEP THE POWER LOADER PERPENDICULAR TO THE GROUND AND ALLOW PROPER OPERATING CLEARANCE.

FIG. 1



FIG. 2

**STEP 3:**

USE THE 2 STABILIZING STRAPS THAT CAME WITH THE POWER LOADER TO SECURE BOTTOM OF BRACKETS TO THE VEHICLE.

**\*\*NOTE\*\*** THE PURPOSE OF THESE STRAPS IS TO KEEP THE BOTTOM OF UNIT FROM BOUNCING AWAY FROM VEHICLE.

**STEP 4:**

REFER TO POWER LOADER INSTRUCTIONS FOR ADDITIONAL OPERATING INFORMATION.

For more information about this or other products, contact us at:

**Great Day, Inc.**

604 Kimbrough Dr. \* Tallulah, LA 71282 \* (866) 649-1918 \* [www.greatdayinc.com](http://www.greatdayinc.com)