

SETTING UP YOUR OVEREZ CHICKEN RUN WHEELS

You will need a drill to install these wheels.

- STEP 1:** **A.** There are two wheels (left & right). Either wheel can be installed on any corner. (Recommended) Pull the chicken run away from the coop a few inches.



- B.** Push the angle bracket on the bottom of the wheel underneath the chicken run corner. Keep the side even with the corner and the top bracket even with the outside.

- STEP 2:** Use the self-tapping screws provided and drive them into the run, through the pre-drilled holes of the wheel frame.



STEP 3:



Pull the lever away from the run. This will lift the run off of the ground. Once the run is lifted off of the ground, you can maneuver it by lifting the opposite end of the wheels then pushing or pulling the run.

NOTE: An additional wheel set can be purchased so that each corner has a wheel.

*for more information about
all our products visit:*

www.OverEZchickencoop.com

