



INSTRUCTIONS:

1. Slide nut onto tubing, threads facing valve.
2. Slide compression sleeve onto tubing.
3. Insert tubing into fitting and tighten nut.