

**Farm Innovators, Inc.
Post Office Box 546
Plymouth, IN 46563
Phone: 800-277-8401**

Instructions for Heated Buckets and Tubs, Models HB-60, FB-80, FB-15R, FB-80R, FB-120, HT-200

WARNING: This is an outdoor product that requires basic safety precautions to minimize the risk of electrical shock, personal injury, and product damage. Read all directions and precautions carefully before putting into operation. When using this electrical appliances, safety precautions must be followed as described below:

1. **Read all instructions before putting this product into use.**
2. Always disconnect your power cord to the product when not in use and during warm weather.
3. **Do not use the product** when obvious damage is noticed to your supply cord or plug. Inspect cord and plug before using.
4. **Do not use the product** if the product has malfunctioned or has been damaged in any manner.
5. **Do not dismantle or puncture the unit for any reason.** This could cause damage and will void the warranty.

Instructions for Use: 120 VAC: This unit is recommended for operational use to -10°F!

1. Place the unit directly on a hard flat surface. **Protect from wind!**
2. Plug the cord into a fully grounded 120 VAC receptacle outlet.
3. Place the unit as to protect from damage by livestock.
4. Fill with water. Do not let the unit operate without water.
5. This product is thermostatically controlled to operate only when temperatures fall below 35F.
6. Inspect the product before using. Read all instructions.

Test for Proper Operation:

(1) Unplug the power. (2) Place the Heated Tub outside in the cold (if temperatures are below freezing) for approximately 45 minutes to re-set the thermostat. (3) After 45 minutes, immediately plug unit into a receptacle outlet. (4) If working properly, the heating element will warm up right away. Within a minute the thermostat should “click” off. The tub is operating correctly.

Limited Warranty

Heated Buckets and Tubs are guaranteed for one year after the original date of consumer purchase or date stamped on the unit against defects due to material and the company’s workmanship only. The sole obligation shall be to replace the defective unit with a replacement unit. Units should be “Checked for proper operation” prior to returning as defective. Units must be returned prepaid. No liability for loss or damage of any nature or kind, whether arising out of or from the use of the product, whether defective or not defective, is assumed by Farm Innovators, Incorporated.

Return address: Farm Innovators, Inc. 2255 Walter Glaub Drive, Plymouth, IN 46563.