


RV Awning De-Flapper Max™

Universal Fit

Includes: Two De-Flapper MAX awning clamps

MAXimum protection from rips and tears
Helps prevent noisy flapping
Works with screen room in place

- No tools needed - easy on, easy off
- UV stabilized nylon strap
- Secure holding power
- Leaves no marks




DIRECTIONS:

No tools needed—Ready to use

1. Locate center of awning nearest each side support arm. Clamp to the center of awning by tightening knob.
2. Pull strap through slot on back of De-Flapper MAX. Wrap strap around support arm. Pull strap through buckle and secure it firmly.

Remove clamp and strap before awning is rolled up into storage position. Store in a dry location for later use.



CAMCO

Camco Manufacturing, Inc.
121 Landmark Dr. / Greensboro, NC 27409
1-800-334-2004 / www.camco.net

z887156