




BAITCASTING REEL

# TATULA TYPE-R 100HL/100XSL

Please order by parts number, not key number  
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name
1	H93-0401	SET PLT SCREW
2	E16-7101	YOKE SPRING
3	H93-0207	BRAKE ADJ KNOB
4	B33-9801	BRAKE DIAL RETAINER(A)
5	F63-7701	BRAKE DIAL WASHER
6	H66-3401	BRAKE CLICK SPRING
7	H94-4902	RIGHT SIDE PLATE
8	H91-5501	BRAKE DIAL RETAINER
9	G93-9301	FRONT PLT SCREW
10	H93-0501	MAGNET HOLDER
11	375-7400	SPACER(A)
12	375-7411	SPACER(B)
13	G18-5101	SPACER(C)
14	G51-1507	BALL BEARING
15	F03-2201	BEARING RETAINER
16-24	Z02-1543	SPOOL ASSEMBLY
25	H94-3902	FRAME
26	H93-0002	FRONT PLATE
27	H45-5402	SET PLT SCREW
28	H91-2401	CLUTCH LEVER
29	H915-701	CLUTCH LEVER PLT B
30	H91-5601	CLUTCH LEVER PLT A
31	H91-2101	STABILIZER BAR
32	H70-4101	RETAINER(A)
33	H91-0601	COLLAR
34	H92-8801	SPRING(B)
35	J05-5201	PIN
36	B86-1704	BALL BEARING(B)
37	H94-4301	PLATE(A)
38	H29-4101	SCREW(D)
39	H47-3301	CLUTCH CAM SPRING
40	H47-3401	CLUTCH TRIP LEVER
41	H94-4001	CLUTCH CAM PLT
42	H15-9201	WASHER(A)
43	352-2501	A/R LEVER SCREW
44	H65-9101	CLUTCH CAM PLATE
45	B03-2904	CLUTCH CAM SCREW
46	H94-4401	YOKE
47	J05-5301	YOKE SPRING
48	H94-4701	PINION GEAR
49	E21-9701	RETAINER(B)
50	G43-1105	BALL BEARING(C)
51	H94-3803	LEFT SIDE PLATE
52	171-5201	"O"RING
53	B17-5406	SPACER(F)
54	B17-5503	CAP RUBBER WASHER
55	J00-4702	CAST CONTROL CAP

Key No.	Part No.	Part Name
56	G04-0814	RIGHT SIDE PLATE SCREW(A)
57	G04-0825	RIGHT SIDE PLATE SCREW(B)
58	320-5901	RETAINER(B)
59	B41-1700	WASHER(B)
60	G72-0001	WORM SHAFT SPACER (A)
61	H92-9101	T-LEVEL WIND
62	121-4212	LINE GUIDE PAWL
63	373-1300	WASHER(C)
64	F40-2801	PAWL CAP
65	H94-4601	LEVEL WIND GUARD
66	H91-1702	WORM SHAFT
67	G72-0001	WORM SHAFT SPACER (B)
68	H91-0501	WORM GEAR
69	B33-9801	RETAINER(C)
70	G09-9800	WASHER(D)
71	320-8002	RETAINER(D)
72	B35-8605	BALL BEARING(D)
73	H92-8901	PLATE(B)
74	E13-4509	SCREW(F)
75	H91-2701	DRIVE SHAFT GEAR
76	J00-9402	DRIVE SHAFT
77	H92-9401	A/R RATCHET
78	F73-3702	DRIVE SHAFT WASHER (A)
79	H94-4801	DRIVE GEAR
80	H45-2602	DRAG WASHER
81	H91-3201	KEY WASHER
82	G54-5001	GEAR SHAFT COLLAR
83	G81-9801	ROLLER CLUTCH
84	B86-1704	BALL BEARING(E)
85	B55-3801	WASHER(E)
86	F02-8203	CLICK LEAF SPRING HOLDER
87	F03-2401	CLICK LEAF SPRING
88	150-8901	DRAG SPRING WASHER
89	H92-9501	WASHER(F)
90	H82-0002	STAR DRAG
91	H66-1701	HANDLE COLLAR
92	H92-9601	HANDLE ASSEMBLY
93	H72-3702	HANDLE SCREW
94	H72-2002	HANDLE CAP
95	G04-0803	HANDLE SCREW

### TATULA TYPE-R 100XSL-SPECIAL PARTS

Key No.	Part No.	Part Name
3	H93-0210	BRAKE ADJ KNOB
48	J01-1301	PINION GEAR
51	H94-3804	RIGHT SIDE PLATE
79	J01-1401	DRIVE GEAR