







Item #14051

#30014051




Hardware: #901688




Step 1

Attach the 4 Hutch Panels and the Run Back using 10 – 1 ½" Screws (B). Attach the 3 Run Panels using 4 – 1 ½" Screws (B).




Step 2

Connect run assembly to hutch assembly using 4 – 2" Screws (A).




Step 3

Slide the Inside Ramp Platform into the hutch, letting it rest in the groove on the Run Back panel. Secure by attaching the Front Support to the hutch assembly using a 2" Screw (A) and a 1 ½" Screw (B).




Step 4


Attach the Ramp using 2 – 2/3" Screws (E) to connect to the Inside Ramp Platform and 1 – 1" Screw (D) to connect to the side of the run.




Step 5 Slide Pull Pan in place on the right side of the hutch assembly.



Step 6 Attach the Run Top to the run assembly using 4 – 2/3" Screws (E). Attach the Rooftop using 8 – 1 3/8" Screws (C).




Step 7 Attach the Ridge Cap using 4 – 1" Screws (D). Attach the Picket Fence using 22 – 1" Screws (D).



D 26pc - 1" screw

Step 8 *Your Premium+ Rabbit Ranch is assembled!*



Care Tip

To protect the wood on your hutch you need to re-apply the protective stain finish at least 1x each year. Use a safe and non-toxic water based stain (available at your local paint or hardware center). Keep hutch in a safe area away from high winds and extreme temperatures.

If you have any questions or concerns about this product contact our customer service department at 1-800-295-2243 Mon-Fri 8:00 – 4:00 MST or email us at cs@waremfginc.com