



Custom Metal Products, LLC


5781 Westwood Dr. Weldon Spring, MO 63304

636-329-0142 www.CustomMetalProd.com

Sniper Target/Stand Assembly Instructions



1) Mount the target body to the post with the two grade 8 hardened 1/2-13 Carriage bolts on the front, with the washers and locknuts on the rear. Never use any lower grade bolt, as they will be damaged by the bullet strikes



2) Mount the targets to the pivot assembly with the grade 8 carriage bolts, washers and locknuts. (These are already mounted when you receive the target assembly)



3) Place the base at the desired target position, and slide the two stabilizer legs into the sockets at the ends of the base assembly.



4) Lining up the V of the post with the V of the base, lower the Target/Post assembly into the socket in the base

5) When the moving target is hit, it will swing to the side. Shoot it again to reset it back to the center position.

After you have read the Target Use and Care instructions on the back of this sheet, the target is ready for use.

Always use approved safety glasses and hearing protection when shooting or observing shooting at any target.

Target Use and Care

The targets produced by CMP are made from AR500 steel for long life and minimum damage due to bullet strikes. The stands, bases and mounting brackets are made from normal steel and can be damaged by repeated bullet strikes, and will not withstand rifle bullet strikes. The design of the targets protects some of the base with the AR500 target face, but occasional hits will occur. The hardware used to mount the targets is Grade 8 and will better withstand repeated bullet strikes. Never use a lower grade of bolt. Replacement hardware is available from CMP.

- Pistol shooting at our targets should be performed beyond a range of 15 yards.
- Rifle shooting at our targets should be performed beyond a range of 100 yards. Bullet velocity must be below 3000 feet per second at target impact.
- Never use armor piercing or steel core bullets to shoot any target
- Always place the target in front of a backstop to capture any bullets which miss the target.
- Always inspect the targets and support structure before and after use for damage and for proper and safe operation.
- Do not use any targets or support structure if any damage or improper operation is found.

Warranty

All CMP products are warranted for one year from date of purchase for defects in material or workmanship. We will repair or replace, at our option, any component found to be defective. Shipping of product back to the manufacturer is the responsibility of the customer. Contact CMP for return shipping instructions.

Limitations of warranty: This warranty does not cover normal wear items such as bolts, nuts, springs, etc. The target faces will become dented and pock marked due to repeated bullet strikes, this is normal wear, and is not covered by the warranty. This warranty does not cover any item that has been modified or altered in any way, used outside its intended purpose, or damaged by acts of nature.