

Instructions on How to Fold the Pet Playpen

Warning: For safety, remove leash and collar before allowing pet to enter the playpen

1. Starting Position



2. Remove the top screen and floor.



3. Find the long zipper and open it.



4. Begin to "accordion" fold each panel. Be sure to keep the elastic band exposed.



5. Once folded flat, wrap the elastic band around the folded playpen and then put in into carrying bag.

