

CONTACT INFORMATION

CUSTOMER SERVICE

M-F 9:00AM-5:00PM CST

Phone:855-965-5310

Email:cs@discoverhomeproducts.com

MADE IN CHINA

PRODUCT MANUAL

4 TIER ROUND TOP GREENHOUSE

MODEL# WHGT801P

WHGT801G

Instruction Guide











PARTS LIST

IMPORTANT

Please check that all parts are included before assembling.

For ease, separate all contents by part number.

Do not use a hammer to insert plastic connectors into tubes.

Serial No.	Description	Picture	Qty	Serial No.	Description	Picture	Qty
A	Short Pole		12	E	Roof Pole		2
B	Long Pole		12	F	Top Wire		1
C	Shelf Support		8	G	Cover		1
D	Roof Pole		2	H	Wire Shelf		4


INSTRUCTIONS:

1. Connect corners and pipes together to construct the main frame.
2. Assemble the top frame.
3. Unfold the cover (Part G) and stretch it over the frame.
4. Pull the cover down to help hold the frame together when you move it.
5. Insert wire shelves (Part H) after the frame is assembled.
6. Now you can enjoy your 4 Tier Round Top Greenhouse.

NOTE:

Greenhouse covers should be removed when outside temperatures reach 60 degrees or above. Extreme heat and sun will melt the plastic cover.

ASSEMBLY INSTRUCTIONS



WARRANTY

90 day Limited Warranty

This product is warranted to the original purchaser against defects in workmanship and materials. If a product fails during the first 90 days from date of purchase under the terms of our limited warranty, please contact customer support. Manufacturer reserves the right in the case of discontinued or out of production models, to replace with an item of similar quality.

Frames

Frames are warranted against defects in materials and workmanship from the date of original purchase. Damage to frame or welds due to commercial use, improper assembly, exposure to water and sub-freezing temperatures, and/or abuse are not covered.

Cover

The cover is warranted against separation at the seams. Fading, mildew and/or discoloration due to exposure to the elements, chemicals and spills are not covered.

Note

Greenhouse covers should be removed when outside temperatures reach 60 degrees or above. Extreme heat and sun will melt the plastic cover.

WARRANTY

Metal Finishes and/or Paint

The finish is warranted against blistering, peeling, or cracking. Fading resulting from exposure to elements, chemicals, and spills are not covered. Scratches and chips due to normal wear and use are not covered.

Note: You must retain original receipt to obtain warranty!

Exclusions

- Damage caused by acts of nature.
- Wind damage.
- Failure caused by unreasonable, unanticipated or abusive use.
- Normal fade due to sun exposure.
- Bursting or cracking of tubing due to exposure to water and freezing temperatures.
- Warranty will be void without original receipt.