

# FABRIC REMOVAL INSTRUCTIONS



Fabric can become soiled over time with use. For stubborn stains or extreme soiling, removal of fabric can make clean up easier.



## CARE

Use a damp cloth to clean. Do not use chemicals. Do not machine wash  
**WARNING!** Not to be used as a children's ride wagon.


## TO REMOVE THE FABRIC

### Step 1



The fabric of the wagon is secured at the front and back of the frame with hook and loop fasteners. Release all to begin the fabric removal process.

### Step 2



Release the hook and loop fastener loop securing the fabric to the frame under the wagon.

### Step 3



The wagon fabric can now be removed from the frame by sliding it down the wagon handle.


## TO PUT THE FABRIC BACK ON

### Step 1



Slide the fabric back into the frame from the front. Be sure the wagon handle is inserted inside the front handle of the fabric.

### Step 2



Resecure the hook and loop fastener loop securing the fabric to the frame under the wagon.

### Step 3



Secure the wagon fabric to the frame with the hook and loop fasteners.