



GARDEN SHED FITTING SKYLIGHT INSTRUCTIONS

FOLLOW THE STEPS IN THE APPROPRIATE
GARDEN SHED ASSEMBLY INSTRUCTIONS
FOR FITTING ROOF SHEETS

Step 1

Choose the position for the skylight.

Fit one skylight in place of one standard roof sheet.

IMPORTANT:

Long edges of the skylight **MUST** underlap the roof sheet and/or roof starter at both sides.

Secure with screws, nuts, bolts and washers as shown. See Diagram.

