

HEATER OPERATION


TO TURN ON THE HEATER

- Turn on the valve on the gas supply cylinder completely.
- Press lightly and turn on the variable control knob to PILOT position.
- Press down the variable control knob and hold for 30 seconds. While holding down the variable control knob, press the igniter button several times until the pilot flame lights. Release the variable control knob after the pilot flame lights, keep control knob depressed for 30 seconds.
- Press lightly and turn the variable control knob to HI (maximum) position and leave in there for about 5 minutes, then turn the variable knob to switch to desired temperature position.

Note: A 5-minute complete shut off period is necessary before relighting.

TO TURN OFF THE HEATER

- Turn the variable control knob to PILOT position.
- Then press lightly and turn the variable control knob to OFF position.
- Turn off the valve on the gas supply cylinder to shut down the heater completely.



Variable control knob

Igniter



Model		Serial No. :
Country Code	CA-US	Gas : Propane
Cat.	2901 01/81	Approval No.: 267527
P (IWC) manifold pressure	11" WC	
Qn (HI)	9500 Btu/hr	

- This heater is for outdoor use only.
- Please read the operating instruction before installation.
- Keep combustible materials away from the heater.
- To turn off the heater, first turn the variable control knob to PILOT position, then press and turn the knob to OFF position. Turn off the valve on the gas supply cylinder completely.

For Outdoor Use Only. If Stored indoors, Detach and Leave Cylinder Outdoors.

APPLICABLE STANDARDS :

ANS Z83.26-2014 • CSA 2.37-2014 Gas-Fired Outdoor Infrared Patio Heaters

PAY ATTENTION TO THE FOLLOWING INFORMATION ABOUT CYLINDER:

- Do not store a spare LP-gas cylinder or near this appliance.
- Never fill the cylinder beyond 80 percent full ; and
- If the information in "n (1)" and "n (2)" is not followed exactly, a fire causing death or serious injury may occur.

Minimum heater clearances from combustible materials: three (3) feet from the sides & two (2) feet from the top.

"For installation on (or over) Noncombustible floors only "

⚠ WARNING: Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.

⚠ CAUTION: The gas pressure regulator provided with appliance must be used. This regulator is set for an outlet pressure of 11in wc.

⚠ CAUTION: Hot while in operation. Do not touch. Keep children, clothing, furniture, gasoline and other liquids having flammable vapors away.

The gas supply must be turned off at the LP-gas supply cylinder when this appliance is not in use.