

HEATER OPERATION

TO TURN ON THE HEATER

1. Turn on the valve on the gas supply cylinder completely.
2. Firmly press down and turn the variable control knob approximately 90°(counter anti-clockwise).
3. Press down the variable control knob and hold for 20 seconds. while holding down the variable control knob, press the igniter button several times until the pilot flame comes on. Release the variable control knob after the pilot flame lights.
4. If the pilot does not light, repeat step 2 to 3.

Note: If a new tank has just been connected, please allow at least one minute for the air in the gas pipeline to purge out through the pilot hole.

5. After the flame comes on, leave the variable control knob at minimum position for about 5 minutes, then switch to a desire temperature position.

TO TURN HEATER AND PILOT OFF

1. Turn control knob to "pilot" position.
2. Then, press down lightly and turn to "OFF" position.
3. Screw off the gas supply cylinder from the regulator.
4. A 5 min. complete shut off period is needed before the appliance is relighted.

