

# Easy Walk® Harness

## How To Measure

1

Chest Width – Wrap measuring tape across chest over the breast bone to approximately 1 inch behind the front legs

2

Girth – Wrap measuring tape around the deepest part of the dog's rib cage behind the front legs



Harness Size	Chest Width	Girth Measurement	Weight
Petite	6"-7"	12"-16"	Under 10 lbs.
Petite / Small	8"-9"	13"-18"	10-15 lbs.
Small	8.5"-11"	15"-21"	15-25 lbs.
Small / Medium	11"-13"	19"-26"	20-30 lbs.
Medium	12"-15"	21"-32"	25-50 lbs.
Medium / Large	14"-18"	24.5"-34"	40-65 lbs.
Large	16"-21"	27"-40"	65-95 lbs.
Extra Large	17.5"-23.5"	32"-50"	90+ lbs.