



ASSEMBLY INSTRUCTION

ITEM # L-GZ762PST-B



IMPORTANT:

- 1, When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and use.
- 2, Some parts may contain sharp edges, wear protective gloves if necessary. At least five or more people are recommended for safe assembly.
- 3, Keep all children and pets away from assembly area.
- 4, At least 6 feet from any obstruction such as fence, garage, house, overhanging branches, laundry line or electrical wires.
- 5, Do not use the unit during an electrical storm, as there is a remote chance of getting struck by lightning
- 6, Do not leave the gazebo assembled when there is a risk of high wind, as possible damage will occur to the structure. Remove fabric roof and secure screen & privacy panels to poles.
- 7, Install on level surface.
- 8, Never barbecue under this gazebo or use lanterns that have open flames.
- 9, This package contains small items and plastic bags that should be kept away from children.
- 10, Check all nuts and bolts for tightness before and during usage. Ensure that all connectors and poles are firmly secured in position fully. It is important to do so before use so as to avoid a possible collapse or damage to the item, which could also result in injury
- 11, This gazebo is intended for decorative and sunshade purposes only and is not meant to withstand extreme weather conditions including high winds, torrential rain and snow. Gazebo fabric is water resistant, not water proof and may leak during exposure to precipitation.

WARNINGS:






- 1, Assembly Instructions must be followed
- 2, Pegs supplied must be used to hold this gazebo in place when upright.
- 3, Warranty does not cover damage due to extreme weather conditions.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC

This Tent Is Made With Fabric That Meets CPAI - 84 Specifications For Flame Resistance. It Is Not Fire Proof. The Fabric Will Burn If Left In Continuous Contact With Any Flame Source

This unit is heavy. Do not assemble this item alone.

Parts List

Small roof Connector	A1	1	
Large roof Connector	A2	1	
Decoration	B1	1	
Hook	B2	1	
Small roof Pole	C3	4	
Upper bar	C4	4	
Slant beam 1	E2	4	
Slant beam 2	D1	4	
Slant beam connector	E3	8	
Beam1	F	4	
Beam 2	G	2	
Beam 3	H	2	
Post1	I	4	
Post 2	J	4	
Large railing	K1	4	
Small railing	K2	8	
Small canopy	L	1	
Large canopy	M	1	
Mosquito netting	N	1	

Hardware Pack 1

AA	knob	32 PCS	
----	------	--------	---

Step. 1






Fig.1: Insert small railing (K2) and large railing (K1) into the plate of the post I (J) then tighten the connections with knob (AA).

Fig.2: Insert the beam (F,H,G) into the plate of the post I (J),then tighten the connections with knob (AA)

Hardware Pack 2

FF

stakeΦ6*180

16 PCS



Step. 2








Fig.3: Insert the upper bar (C4) into the connecting tube of large roof connector(A2), secure the hook (B2) to the large roof connector (A2)

Fig.4: Insert the beam 1(D1) and beam 2(E2) into the connecting tube of upper bar (C4)

Fig.5: Insert the slant beam 1(E2) and slant beam 2(D1) into the connecting tube of slant beam connector (E3)

Fig.6: Insert the slant beam connector (E3) into the post I (J), then put the large canopy (M) on the assembled large roof, do not unfold







Fig.7: Insert the small roof pole (C3) into the connecting tube of small roof connector (A1), then put the small canopy (L) on the assembled small roof, do not unfold it completely.

Fig.8: Screw the decoration (B1) into the small roof connector (A1), then attach the small canopy along the small roof pole(C3), aligning the corners and stretching it to fit it.

Fig.9: Put the large canopy (M) on the beam, do not spread it. Insert the small roof pole (C3) into the connecting tube of upper bar (C4). Then put the large canopy on top of the assembled beam.

Fig.10: Secure the completely assembled gazebo on the ground by using stake (FF)

Hardware Pack 3

BB

Plastic ring

52 PCS



Step. 3





Fig.11: Attach the mosquito netting (N) on the beam H(F,G) with plastic ring (BB)