


ASSEMBLY INTRUCTION

ITEM#: D-AB020PWD



WARNING:

Repeated assembly can weaken the locking ability of the screw/bolt/nut. Periodically check all bolted connections on your product to make sure they are tight and secure. Keep these instructions for future reference.


Some parts may contain sharp edges. Wear protective gloves as necessary.

Set it up on the flat, level ground.

Attention: Please notice there are split lines in the wood logs. These are NOT defects. These are factory created to allow expansion and contracting as the weather changes throughout the year.

Important: For technical assistance or questions, call Sunjoy Group at 1(866) 578-6569 anytime 24 hours / 7 days a week, or email to customer.care@sunjoygroup.com, or visit www.sunjoyonline.com for more information or assistance.

PARTS LIST		
Label	Description	QTY
A	Roof Bar	6
B	Beam	2
C	Left Screen	1
D	Right Screen	1
E	Bottom Board	2
F	Flowerpot Front/Rear Plate	4
G	Flowerpot Side Plate	4
H	Slant Beam	4
J	Seat Connector	2
K	Seat Board	5



HARDWARE PACK		
Label	Description	QTY
AA	M4x40 Screw	46
BB	M6x70 Bolt	8
CC	M6 Flat Washer	16
DD	M6 Nut	16
EE	M6x55 Bolt	4
FF	M6x75 Bolt	4
GG	M6/M8 Wrench	1
HH	Wrench	1

ASSEMBLY STEPS




Fig.1: Connect Flowerpot Front/Rear Plate (F) to Flowerpot Side Plate (G) using Self-taping Screw (AA).
Repeat for other plates.

Fig.2: Connect Flowerpot Side Plate (G) to Flower Front/Rear Plate (F) using Self-taping Screw (AA)

Fig.3: Connect Roof Bar (A) to Beam (B) using Self-taping Screw (AA).

Fig.4: Connect Beam (B) to Left Screen (C) using Bolt (BB), Flat Washer (CC) and Nut (DD). Repeat for Right Screen (D).

Fig.5: Connect Slant Beam (H) to Left Screen (C) using Bolt (FF), Flat Washer (CC) and Nut (DD). Repeat for Right Screen (D).

Fig.6: Connect Seat Board (K), Seat Connector (J) and Right Screen (D) using Self-taping Screw (AA).
Repeat for Left Screen (C).

Fig.7: Connect Slant Beam (H) and Beam (B) using Bolt (EE), Flat Washer (CC) and Nut (DD). Repeat for other slant beams.

Fig.8: Put Bottom Board (E) into the flowerpot in the direction as the arrow.

Limited Warranty:

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item, provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of six (6) months. We do not reimburse for transportation or delivery costs, nor compensate the individual or any outside party for assembling or disassembling the product.

Exclusions:

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.