


ASSEMBLY INTRUCTION



ITEM#: D-AB004PST




WARNING:



1. Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the assembly area of the arbor.
2. Some parts may contain sharp edges. Wear protective gloves.
3. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and usage.
4. For outdoor use only. Install on level ground securely.
5. Check all bolts for tightness before and during usage.
6. Do not leave the arbor assembled when there is a risk of high wind, as possible damage will occur to the structure.
7. Do not climb on the arbor. Falling off the arbor can result in serious injury, possibly even death.

Important: For technical assistance on assembly or replacement parts, please call Sunjoy Industries at 1(866) 578-6569 from 8:00 AM EST to 8:00 PM PST. You may email to customer.care@sunjoygroup.com or visit www.sunjoyonline.com to place your order or fax your parts replacement order form (which is included in the packaging) together with your purchase receipt to 1 (740) 283-3549 for assistance.


PARTS LIST			
Label	DESCRIPTION	QTY	Image
A	Beam	5	
B	Supporting Bar	2	
C	Screen	2	
D	Screen Supporting Bar	2	
E	Lantern	2	

HARDWARE PACK			
Label	DESCRIPTION	QTY	Image
AA	Bolt M6*15	16	
BB	Washer M6	34	
CC	Hex Bolt M6*15	8	
DD	Bolt M6 x 35	10	
EE	Wrench	1	
FF	Φ6*180 Stake	4	


ASSEMBLY STEPS




Step 1: Attach supporting bar (B) to screen (C) with bolts (AA) and washers (BB).




Step 2: Attach screen supporting bar (D) to screen (C) and supporting bar (B) with hex bolts (CC) and washers (BB).



Step 3: Attach beam (A) to supporting bar (B) with bolts (DD) and washers (BB).



Step 4: Hang lanterns (E) to hooks on screen (C).



Step 5: Secure the assembled arbor to ground with stakes (FF).

Limited Warranty

The item is warranted to be free from defects in material or workmanship for a period of six (6) Months. However, we don't reimburse for transportation or delivery costs, or compensate the individual or any outside party for assembling or disassembling the product. This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item, provided the item is maintained with care and used only for personal residential purposes.

Exclusions

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

Maintenance

Our iron/steel components for garden accessories and furniture are coated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur once these protective coatings are scratched. This is a natural process and is not a defect! To minimize this condition, we recommend care when assembling & handling the product to prevent scratching the paint. Should any scratching or damage occur, we recommend immediate touch-up with rust inhibiting paint. Surface rust can also be easily removed with a very light application of common cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping on to deck or patio and cause damaging stains, which may be difficult to remove. This can be prevented if measures are taken to keep the product from oxidizing.