


ASSEMBLY INSTRUCTION

ITEM#: D-CH729PPS



SAFETY INFORMATION

Please read instructions thoroughly before assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to assure safe and proper assembly.

Periodically check all bolted connections on your product to make sure they are tight and secure. Please keep the instructions for future reference.

WARNING:

Tighten the screws and nuts but DO NOT overtighten them.

DO NOT operate it if any part is damaged or broken.

Place the product in an area away from children and pets.

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 5 minutes

Tools Required for Assembly (Not included): Screw driver


Important: For technical assistance on assembly or replacement parts, please call Sunjoy Industries at 1(866) 578-6569 from 8:00 AM EST to 8:00 PM PST or email to customer.care@sunjoygroup.com or visit www.sunjoyonline.com to place your order or fax your parts replacement order form together with your purchase receipt to 1-740-283-3549 for assistance.

PARTS LIST			
Label	Description	QTY	Image of Part
A	Handle with hanging chain	1	
B	Support bar	6	
C	Lamp Shade (Pre-assembled)	6	
D	LED Chandelier Connector	1	
E	Battery Cover (Pre-assembled)	1	




HARDWARE PACK			
Label	Description	QTY	Image of Part
AA	Screw M6*10	6	
BB	Screw M4*16	12	
CC	Nut M6	6	

ASSEMBLY STEPS




Step 1: Put nut (CC) into the nut hole on the support bar (B).




Step 2: Attach one end of support bars (B) to the inside of handle with hanging chain (A) using long screws (AA). Hand tighten only.

Fig. 3




Step 3: Take down the prebuilt screw (BB) from LED chandelier connector (D).

Fig. 4



Step 4: Attach support bar(B) with connector (D) using screw (BB) and then tighten them.

Fig. 5



Step 5: Open the battery cover (E) as shown, put three AA batteries (not included) into the battery box and then reattach the battery cover.

Note: Ensure the polarities on the batteries match those shown on the battery box.

WARNING:

Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel-Cadmium) batteries. If you find any noise, excessive temperature or leakage from a battery, please discard. When not using the unit for a considerable period of time, disconnect the batteries from the unit for storage. If battery power is weak during use, switch off the device and dispose of batteries.

CAUTION:

Assemble on a soft, non-abrasive surface.

Don't fully fasten the bolts until all bolts are in place. Changes or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.

CARE AND MAINTENANCE:

Immediately remove any spot or stain.

Please do not wash electrical parts.

Do not use strong solvents or bleach as they may damage the surface.

When not using the unit, stock the light to extend its working life.