


# ASSEMBLY INTRUCTION




## ITEM#: S-UM278PST




### **Warning**

- Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- Check all bolts for tightness before use, and periodically check and tighten bolts as necessary.


**Important:** For technical assistance on assembly, please call Sunjoy Industries at 1(866) 578-6569 anytime 24 hours / 7 days a week, or email to [customer.care@sunjoygroup.com](mailto:customer.care@sunjoygroup.com), or visit [www.sunjoyonline.com](http://www.sunjoyonline.com).

| PARTS LIST |                |     |   |
|------------|----------------|-----|---|
| Label      | Description    | QTY | Image   |
| A          | Umbrella Shade | 1   |  |
| B          | Lower Pole     | 1   |  |
| C          | Solar Panel    | 1   |  |


**ASSEMBLY STEPS**




**Step 1:** Insert the plug into the socket under the solar panel(C).



**Step 3:** To assemble the two pole pieces together: Insert the bottom pole into the upper pole while pressing the snap button on the bottom pole until the snap button locks into position.




**Step 2:** Put the solar panel on the top of umbrella and hide the plug and wire inside the groove at the top of umbrella. Then turn the solar panel clockwise. Do not over tighten. Please remove the plastic film on the solar panel. \*This protective plastic film is to prevent damage during shipment.




**Step 4:** We recommend that you stand and secure the umbrella to an umbrella base (not included). Secure the umbrella pole firmly by tightening the locking nut.

\* Reverse the set-up steps above to take down the umbrella.



**Step 5:** Put the solar umbrella in the sunlight to charge the batteries before the first use. Make sure to charge the batteries for at least 8 hours before the first use. Otherwise it will shorten lifespan of the batteries and decrease performance. If charging the solar panel while attached to the umbrella, make sure the switch on the pole is in the off position.



**Attention:** If there are more than 2 devices are within 15ft of the Bluetooth umbrella, when one device is connected successfully at first, the other devices will not be connected successfully.

**ATTENTION: You must charge batteries before first use.**

⚠ Please note that battery can discharge if they are left unused or uncharged for a long period of time. Since there can be a six-month period between production and final customer purchase, we recommend you charge your solar umbrella for at least 8 hours in direct sunlight before the first use. Failure to charge the battery will result in premature dimming of the lights in your new solar umbrella.

For everyday normal use, turn on the light switch at night when you want to use solar light and turn off the switch after use.

⚠ NOTE: PLEASE REMOVE THE PLASTIC FILM ON THE SOLAR PANEL BEFORE CHARGING IN THE SUN.

⚠ NOTE: IF LIGHTS ARE NOT WORKING PLEASE CHECK BATTERY IN SOLAR PANEL TO SEE IF IT HAS BEEN INSERTED PROPERLY.

**Step 6:**


- Turn the crank the handle (1) in a clockwise direction to open the umbrella canopy (A), and in a counter-clockwise direction to close the umbrella canopy (A).
- You can tilt the umbrella to your desired angle by pressing the tilt button (2) to release the top of the umbrella. Release the button (2) to maintain the desired angle.
- Press the light switch (3) on the crank housing to turn on/off the solar lights. Press once to turn on the rib lights, press twice to turn on the hub lights, press three times to turn on both the rib lights and the hub lights, and press four times to turn all lights off again.
- Press the green blue tooth sensor button (4) to turn the blue tooth speaker on, and there will be a voice prompts “The blue tooth device is ready to pair”. You must be within 15 ft of the umbrella to search from your device for the blue tooth umbrella. Your device will read “Umbrella BT-SPK”. There will be a voice prompts “The blue tooth device is connected successfully” when it is connected successfully. Press the green blue tooth sensor button (4) to turn the blue tooth speaker off. The blue tooth speaker will automatically turn off if it cannot find any devices within 5 minutes. If you need to turn on the blue tooth speaker again, you need press the green bluetooth sensor button (4) to turn it on.

## **How to Replace Batteries**


We recommend that you change the battery in your solar light umbrella every year or when you feel the light output is diminished. For best results buy (1) 18650 Lithium 2200mAh rechargeable battery same as supplied with panel. Install only new batteries.

\*Failure to insert battery in the correct polarity, as indicated in the battery compartment, may shorten the life of the battery or cause the battery to leak. Do not dispose of battery in fire. Battery should be recycled or disposed of as per state and local guidelines. Do not mix old and new batteries. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.


**Tools required: Philips head screw driver (not included).**




**Step 1:** Twist counterclockwise and remove the solar panel from the top of the umbrella.




**Step 2:** Pull the plug out of the socket under the solar panel. Pull by holding the plug, not by pulling on the wires.



**Step 3:** Put the solar panel upside down on a flat, non-abrasive surface to avoid scratching. Loosen all four (4) screws on the solar panel bottom case.



**Step 4:** Carefully open the bottom case and set aside. Fig.10. Replace the batteries, matching the +/- on the batteries with the +/- on the battery case.



**Step 5:** Carefully put the bottom case back. Align the screw holes and replace the screws. Do not over tighten the screws.

### **SAFETY INFORMATION:**

- Always put the umbrella in the down position when not in use.
- Securely fasten the umbrella to an appropriately sized umbrella base. Do not install into the ground.
- This seasonal use product is not intended for permanent installation or use.

DANGER: Do not use near open flame or other heat sources.

CAUTION: Do not use the umbrella in windy conditions, store the closed umbrella in place.

CAUTION: Do not attempt to alter the wiring or operate the umbrella in place.

CAUTION: Do not use this product for other than its intended purpose.

### **BATTERY RECYCLING**

Please dispose of used batteries properly. Consult your local telephone listings for a battery recycling center near your area.



Do not dispose batteries in household waste.



Do not throw batteries into water.



Protect batteries against heat and fire due to risk of explosion.



Recycling.

**Care & Maintenance:**

- Before using, clean the product completely with a soft dry towel.
- When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water; rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners.
- Steel components of garden accessories and furniture are treated with rust inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched.
- To minimize this condition, it is recommended that care be taken when assembling and handling the product, in order to prevent the paint from being scratched.

**Limited Warranty:** The item is warranted to be free from defects in material or workmanship for a period of six (6) months. However, we do not reimburse for transportation or delivery costs, nor compensate the individual or any outside party for assembling or disassembling the product. This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item, provided the item is maintained with care and used only for personal residential purposes.

**Exclusions**

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.