



DIRECTIONS FOR ERECTING THE WALLUP![®]



Before erecting the Wallup remember not to “muscle” the product together but rather “manipulate” it. When manipulating the screen onto the vertical poles bend the poles like a bow using your elbow and knee. When taking the Wallup out of the bag unzip it ALL THE WAY and remove it from the end rather than the top of the bag. If you have any question while assembling please call us.




Step 1. Place the fabric so the side with the Velcro is facing upward. The stakes and poles need to go on the side of the Velcro.


Step 2. Insert the stakes through the grommets and into the ground using a large hammer. Try to ensure the stakes are standing vertically upright and the hammer is large enough you don't damage the inside hole of the stake. If using a small hammer try to hit the stake on the outside rim. Ensure the grommets and stakes are as far apart from each other as the fabric will allow, i.e. the screen fabric is tight between grommets.

Step 3. Insert the four upright two-piece poles into the stakes. The metal end of the pole goes into the stakes.

Step 4. Insert the long rod into a hole on the upper corner of the screen (either hole on either upper corner where the upright pole will insert into). Make sure it is all the way through and touching the other end of the fabric. Once the rod is all the way inserted, holding on to the fabric, force it past the hole into the screen and let it “spring” back inside the corner of the screen. The rod should now be completely inside the sleeve on the top of the screen.



Now you should have the stakes into the ground, the smaller rod inserted into the top of the screen, and the large poles standing vertical in the stakes.



Step 5. When completing this step it's easiest to start on the right side and work your way left. Lift the fabric on one corner and insert the outside vertical rod into the receptor on the top of the screen. You will have to bend the vertical rod like a “bow” to do so. It's easiest if you practice bending the rod first and manipulate it rather than trying to muscle the screen onto the pole. It is best to grab the top of the pole with your hand keeping your elbow on the side your body is on and bend it using your elbow, maybe even your knee to help. Using your left hand place your thumb inside the receptor on the screen creating a “cup” so it's easier to insert the tip of the rod. It's sometimes helpful to twist the pole to seat better inside the receptor. Complete this step with the remainder uprights and fasten the Velcro onto the poles.



PACKING THE WALLUP!

- Step 1. Drop the wall off the upright poles, again bending the poles.
- Step 2. Remove the upright poles and stakes.
- Step 3. The most difficult part of packing the Wallup! is taking the top rod out of the upper sleeve. To do this remove one end, go to the opposite end and push the rod out.
DO NOT DO NOT TRY AND PULL THE ROD OUT!
- Step 4. Fold the screen in half lengthwise
- Step 5. Place the rods and stakes on the screen.
- Step 6. Roll the screen tight with the parts inside it and place it in the bag from the unzipped end.

TIPS AND TRICKS

When pounding the stakes in the ground it is best to use a 2lb or heavier maul. This keeps the top of the stake from being banged up and helps the stake drive into hard surfaces. The heavier the maul the better. If a stake will not pound in the ground due to a rock try to move in a few inches or more from side to side to avoid it. As a last resort the wall can stand erect with less than four stakes. The best shape for looks and to withstand the wind is a concave or convex shape. In some soils you can set the Wallup and move it without disassembly. In harder surfaces you can remove the upright poles and pound the stake back in wherever you want. If you want to view the surrounding areas you can take the screen off any number of poles to allow the screen to sag. Taking the screen off the two center poles will drop the middle of the screen to about eye level. The smaller rod that inserts into the top is simply to help keep the top of the screen in shape and if you bend it too hard it will break. You can tie off the Wallup from the rods or put grommets anywhere you want. You can have something silkscreened on or put a zipper window in it. You can sew pouches on it for holding things. We encourage you to be creative with your Wallup!

WARRANTY

All products sold by **Kittrich Corporation** are warranted by **Kittrich Corporation** directly to the purchaser. All products are guaranteed for 6 months from the original purchase date. If the Wallup! doesn't perform properly due to a defect in material or workmanship, **Kittrich Corporation** will, at its discretion, repair or replace all or part of the product. In order for warranty to be valid original purchase receipt is required as proof of purchase and the purchaser is required to return to **Kittrich Corporation**, parts that need repaired. If **Kittrich Corporation** determines parts are defective Inman Innovations will replace the part in need of repair, pay for shipping, and refund purchaser their original shipping costs. Inman Innovation may, at its option, replace the parts or refund the amount paid by customer.

No warranty or affirmation of fact, express or implied, other than as set forth in the limited warranty statement above, is made or authorized by **Kittrich Corporation**. **Kittrich Corporation** disclaims any liability for claims arising out of product misuse, improper product selection, improper installation, product modification, misrepair or misapplication.

Kittrich Corporation expressly disclaims any liability for consequential, incidental, special, exemplary, or punitive damages. **Kittrich Corporation** liability in all circumstances is limited to, and shall not exceed, the purchase price paid for the product that gives rise to any liability. Before returning any product, customer shall contact **Kittrich Corporation**.

Proof of purchase is required in all cases. Customer is obligated to return product to **Kittrich Corporation**. Product returns must be made within 60 days from date of purchase, unless otherwise approved by **Kittrich Corporation**.