



WARNINGS & INSTRUCTIONS

LOADING RAMP USE INSTRUCTIONS:

- Read and understand all manufacturer's instructions before using.
- When loading or unloading from a vehicle, fully engage emergency brake, chock wheels, and turn off engine.
- Place the ramp ends on even ground with a firm surface.
- Place ramp(s) or sections on ground/base surface with threshold bar/fingers completely resting on tailgate or loading surface.
- Confirm wheel spacing by positioning vehicle/equipment directly in front of ramp(s).
- Secure safety strap hook(s) to bumper or frame of loading vehicle, adjust strap(s) as required.
- Strap(s) should be taut.
- Test ramp sections to confirm lack of movement prior to use.



LOADING RAMP USE WARNINGS:

- Never ride any vehicle up or down loading ramp(s).
- Do not step between ramp cross bars.
- Ramp surface and other metal components may be slippery when wet.
- Do not use as a ladder, bridge, scaffolding, or for any purpose other than that for which it was designed.
- Do not exceed load capacity of tailgate, ramp(s) or other loading surfaces: Consult manufacturer for details.
- Always confirm all bystanders and children are positioned at a safe distance from equipment.
- Exercise extreme caution loading and unloading vehicles/equipment with the ramp(s).
- Keep body parts completely clear of ramp hinge pinch area at all times.