



Grape Solar 150-Watt Off Grid Kit (GS-150-KIT) Quick Connect Guide

IMPORTANT: Please read the Panel User Manual (formerly titled the Safety & Installation Manual), the kit sizing guide (available at www.grapesolar.com/manuals.html) and the PWM-165 manual before following the steps in this guide.

Exclusion for Documentation

UNLESS SPECIFICALLY AGREED TO IN WRITING, SELLER

MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY, OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MANUALS OR OTHER DOCUMENTATION;

ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSSES, DAMAGES, COSTS OR EXPENSES, WHETHER SPECIAL, INDIRECT, CONSEQUENTIAL OR INCIDENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK; AND

REMINDS YOU THAT IF THIS MANUAL IS IN ANY LANGUAGE OTHER THAN ENGLISH, ALTHOUGH STEPS HAVE BEEN TAKEN TO MAINTAIN THE ACCURACY OF THE TRANSLATION, THE ACCURACY CANNOT BE GUARANTEED. APPROVED CONTENT IS CONTAINED WITH THE ENGLISH LANGUAGE VERSION WHICH IS POSTED AT WWW.GRAPESOLAR.COM/MANUALS.HTML

Important: Installations of this kind must be certified/approved as “code-compliant” to the national and local building and electrical codes. Installers should have adequate knowledge of national and local code to ensure the installation passes inspection by the local electric authority.

Important: Proper fuses or breakers should be used to comply with all local and national codes. Contact Grape Solar for specific recommendations.

Important: All batteries used for this system should be identical. Batteries must be deep cycle. Do not mix battery types or sizes. Do not mix old batteries with new batteries. Performance and charging anomalies can occur if types, sizes, or age of batteries are not identical.

Step 1: Check your order to make sure that all parts are included. For the GS-150-KIT, this is:

3 pc GS-STAR-50W solar panels,

2 sets of T-branch connectors to put the panels in parallel

1 pcs 25-foot MC4-to-bare cables,

1 pc red/black 5-foot bare-wire-to-ring-lug cable pair, (charge controller to battery) and

1 pc Grape Solar PWM-165 charge controller.



©Copyright 2017, Grape Solar, Inc. All Rights Reserved



Step 2: If you are connecting the system during daylight, cover the panel with cardboard, cloth, or a similar option so that it does not output power. Place the panel so it is facing due south at approximately the same angle as your latitude, in full sun.



Step 3: Mount the controller if desired (note that it must be in a NEMA-4 rated enclosure if it is outdoors). Use the 5-foot red & black cable pair to connect your positive and negative battery terminals to the battery inputs on the charge controller.



Step 4: Attach the lug end of the red cable to the positive terminal on the battery. Attach the lug end of the black cable to the negative terminal on the battery. If your battery has sufficient charge (11.5 volts or more), you should now see the LCD display light up on the controller. This means the controller has power (controllers are powered by the battery, not the panels).



Step 5: Connect the positive and negative outputs of the panels to the appropriate T-branch connectors, as seen below. Panels 2 and 3 connect to the 1st pair, and the outputs of that 1st pair along with Panel 1's outputs connect to the second pair.



Step 6: Connect the MC4 outputs of the T-branch connectors to the MC4 ends of your two 25-foot pieces (we recommend marking the bare wire positive end with tape, to differentiate the leads). Then connect the bare wire ends to the controller.



Step 7: Uncover the panel. As the day progresses, you should see the battery charge percentage increase until it is reading 100%. Once the battery is fully charged, you can use it to provide power through an inverter or through the load control output of the PWM-165.

FOR MORE DETAILED INFORMATION, INCLUDING INSTALLATION GUIDES AND MANUALS, SEE:

WWW.GRAPESOLAR.COM/MANUALS.HTML

©Copyright 2017, Grape Solar, Inc. All Rights Reserved