



# Vehicle Recovery Ring

## 10,000 lb. Capacity

Model Number: 70655



### Product Features:

- Fits 2" receiver openings
- 360 degree rotation
- 180 degree pivot
- 10,000 lb. capacity in any direction
- Unique patent pending design inspired by the proven military design

### Key Benefits:

- For multi-purpose off-road vehicle recovery and utility pulling and hauling.
- Safe and effective recovery for multiple vehicle types in unique angle or elevation situations.

### How it is Made:

- Plated ring for durability and corrosion resistance
- Tested by independent and accredited labs



**This Instruction Sheet contains IMPORTANT safety information. Please read and keep for future reference.**

**For assistance with this product or to order replacement parts, please contact:**



**Cequent Consumer Products, Inc.  
29000-2 Aurora Road  
Solon, OH 44139  
Technical Service: (800) 234-6992  
CequentConsumerProducts.com**

**Date of Purchase:** \_\_\_\_\_

## **⚠ WARNING**

### **READ and FOLLOW all instructions and safety messages before using the Vehicle Recovery Ring.**

An improperly attached or overloaded **Vehicle Recovery Ring can break or DETACH WITH GREAT FORCE**. If the Vehicle Recovery Ring, any strap or any hardware still attached strikes a bystander or person in the recovery vehicles, it can cause death, serious injury or damage to the vehicles.

#### **TO REDUCE THE RISK OF SERIOUS INJURY OR DEATH:**

##### **Know how to safely use Vehicle Recovery Ring**

- READ and FOLLOW all warnings when using the Vehicle Recovery Ring.
- ALWAYS take your time to assess your situation and plan your recovery carefully.
- Consider a 4WD training course for recovery techniques.

##### **NEVER exceed the 10,000 lbs. capacity of the Vehicle Recovery Ring.**

- DO NOT exceed your vehicle manufacturer's recommended towing capacity. Consult the owner's manual for your vehicle.
- ONLY use a recovery strap with a breaking strength less than the 10,000 lb. capacity of the Vehicle Recovery Ring.

##### **INSPECT for signs of wear, rust and damage BEFORE each use**

- DO NOT use if damaged.

##### **CHECK the Vehicle Recovery Ring is properly attached using a hitch pin and clip.**

##### **KEEP OUT of the Danger Zone**

- Bystanders can be struck by recovery strap recoil or unexpected movement of the vehicles.
- ALWAYS move bystanders a safe distance from the recovery area.
- KEEP OUT of the recovery vehicles path.
- NEVER stand in front of, between or behind vehicles during recovery. Vehicles could move suddenly and unexpectedly.
- ONLY persons involved in the recovery should be in either vehicle.

##### **AVOID shock loads**

- DO NOT impact, jerk and/or swing the load during recovery. These actions can overload your Vehicle Recovery Ring and cause it to break or detach.

##### **NEVER use for conventional towing of vehicles, trailers or RVs on the roadway**

**When not in use, the Vehicle Recovery Ring should be removed from your hitch and stored in your vehicle.**

**THIS WARNING IS GIVEN IN COMPLIANCE WITH CALIFORNIA PROPOSITION 65**

**WARNING:** This product contains chemicals known to the state of California to cause cancer birth defects or other reproductive harm.

**REESE One (1) Year Limited Warranty**

1. **Warranty.** Cequent Consumer Products, Inc. warrants to the original consumer purchaser ("You") that the Product will be free from defects in material or workmanship for one year from the date of your retail purchase. Cequent Consumer Products, Inc. makes no other warranties. If the Product does not comply with the Warranty, Cequent Consumer Products, Inc. will replace the Product without charge and within a reasonable time or, at Cequent Consumer Products, Inc. option, otherwise refund the purchase price.
2. **Limitations on the Warranty.** The Warranty does not cover the following: (a) normal wear and tear; (b) service or labor charges incurred in removing or replacing any Product; (c) the finish on the Product; (d) a Product that has been damaged through abuse, neglect, misuse or as a result of any accident or in any other manner; (e) a Product which is misapplied, overloaded, or improperly installed; and (f) a Product altered in any manner by anyone other than Cequent Consumer Products, Inc.
3. **Obligations of Purchaser.** To obtain the benefits of the Warranty, You must promptly present the defective Product and proof of purchase to Cequent Consumer Products Inc., 29000-2 Aurora Road, Solon, Ohio 44139 or any of its branches, factories, or authorized dealers listed in local directories. Any returned Product that is replaced or refunded becomes the property of Cequent Consumer Products, Inc.
4. **Legal Rights.** This Warranty gives You specific legal rights, and You also may have other rights which vary from state to state. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON ANY PRODUCT SHALL BE LIMITED TO ONE YEAR FROM THE DATE OF RETAIL PURCHASE BY YOU. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to You.
5. **Remedy Limits.** Replacement of the Product or refund in the manner provided above is Your exclusive remedy and shall constitute fulfillment of all liabilities of Cequent Consumer Products, Inc. to You whether based on contract or otherwise. Cequent Consumer Products, Inc. shall not be liable or assume responsibility for the loss of the use of any vehicle, loss of time, rental of vehicles, loss or damage to personal property, expenses such as gasoline, telephone, lodging, or towing, or any other incidental or consequential damages incurred as a result of the use or ownership of any Product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to You. Any of the above remedy limitations shall be inoperative to the extent they are not permitted by applicable state law.

The proper attachment of this product in accordance with the enclosed instructions is critical to its proper performance. Cequent Consumer Products, Inc. has no control over, or responsibility for, the attachment or the installation. Cequent Consumer Products, Inc. is NOT responsible nor will be held liable for any damage resulting from its attachment or improper use. Cequent Consumer Products, Inc. shall not be liable for any claims of any kind greater than the purchase price of the product. Warranty information available at [www.quent.com/terms](http://www.quent.com/terms)



**Cequent Consumer Products, Inc.**  
**29000-2 Aurora Road**  
**Solon, OH 44139**  
**Technical Service: (800) 234-6992**  
**CequentConsumerProducts.com**