

RV Flexible Swivel Stik™

Holding Tank Rinser with Shut-Off Valve

DIRECTIONS:

1. **HOOK-UP:** Connect Camco RV Flexible Swivel Stik™ to extension hose.
2. **RINSE:** Empty holding tank in usual manner. Leave tank drain valve open.
3. Insert Swivel Stik™ into holding tank through toilet tank and open faucet for full flow.

Use shut-off valve to stop/start flow if necessary while rinsing tank.

***NOTE:** Do not expose unit to pressures in excess of 100 PSI.*

***NOTE:** Keep toilet valve depressed while using. Do not allow valve to snap back against Swivel Stik™. Some types of toilet valves may become damaged by force of contact.*

4. Flush using cold or hot water.
5. **STORE:** Close faucet and open shut-off valve to drain water from hose and RV Flexible Swivel Stik™.

IMPORTANT:

Because the Camco RV Flexible Swivel Stik™ is used inside the high bacteria area of a holding tank, always clean unit thoroughly in strong solution of chlorine bleach before storing.

GENERAL INFORMATION:

Usually you will need to use your Camco RV Flexible Swivel Stik™ only at the end of a trip or when your RV will not be used again for a few days. Normal tank emptying during a trip does not require additional flushing with fresh water except under unusual conditions. Tanks should be emptied and flushed out immediately before storage. Should tank be allowed to dry out, fill with water and allow to stand and soak for several hours. When waste liquefies, dump tank and flush with Camco RV Flexible Swivel Stik™.